

Car Guard remote jamming detector

Technical Datasheet



Wiring Diagram:

Mini USB charger
Plugs directly into 220v AC

Application:

- Alert user of potential jamming of car alarm and central locking.

Specifications:

- 3.7v DC operation, 220v AC charger supplied.
- 433Mhz frequency detection.
- Beeper and vibration motor alerts.
- LCD display with signal strength indication.
- Real time clock with 200 event history FIFO.
- Supplied with carry pouch, mobile detection.
- Physical size: 110mm x 70mm x 20mm.

Installation

- Plug USB charger into 220v AC outlet and into base of CarGuard.
- Press and hold the RED button to turn the unit ON.
- Press and hold any remote on 433mhz, unit begins to beep, display flashes and goes into continuous alarm if jamming continues.

www.comtronix.net

Tel: 011 791 1362/060 384 1775 / **Email:** support@comtronix.net

While every precaution has been taken during the preparation of this document to ensure the accuracy of its content, Comtronix assumes no responsibility for errors or omissions. Comtronix reserves the right to make changes to the product or this document without notice.