

Jam Guard remote jamming detector

Technical Datasheet



Wiring Diagram:

Plugs directly onto car battery

Application:

- Alert user of potential jamming of car alarm and central locking.

Specifications:

- 12v DC operation.
- 433Mhz frequency detection.
- Siren and outputs.
- Adjustable timing before jamming trigger.
- Physical size: 100mm x 50mm.

Installation

- Connect unit to car battery.
- Unit automatically activates when vehicle is turned off, non active while driving.
- Press and hold any remote on 433mhz, unit begins to beep and goes into alarm if jamming continues.

www.comtronix.net

Tel: 011 791 1362/060 384 1775 / **Email:** support@comtronix.net

While every precaution has been taken during the preparation of this document to ensure the accuracy of its content, Comtronix assumes no responsibility for errors or omissions. Comtronix reserves the right to make changes to the product or this document without notice.